

FR FAMILY
F²MC FAMILY
32/16/8-BIT MICROCONTROLLER

Softune LINKAGE KIT ADDITIONAL MANUAL

(Memory Used Information List)

Output Specification of the Map List File Memory Used Information List (-mmi)

This outputs the memory used information of the Map List Files that are output by the Linker.

[Format]

-mmi

[Parameters]

None

[Explanation]

This outputs the memory used information list that indicates the usage conditions of the ROM or RAM areas specified by the options of the Map List Files that are output by the Linker as the default.

It indicates the information about usable area, used area and gap position and size in the area etc.

[Example]

```
flnk911s l0mp00 im_lnk -mmi -ra RAM1=0x1000/0x1FFF, RAM2=0x2000/0x23FF  
-ro ROM1=0xBC000/0xBCFFF, ROM2=0xBD000/0xBFFFF -AL 2
```

Note: The following will not be output despite -mmi being specified.

- (1) The memory area is not specified. (-ra or -ro is not specified).
- (2) The Map List File output is not valid.

Memory Used Information List

The memory used information list displays the name of the area of the RAM specified area or the ROM specified area and the size of the free space or the remainder range and the header and end address of the specified area.

■ Memory Used Information List Field List Output Format

The following shows the memory used information list field list output format.

FR Family Softune Linker	ROM/RAM Used Info List	YYYY-MM-DD hh:mm:ss	Page: 3		
S-Addr.	-E-Addr.	Size	Remain	Name/State	C
(1)ROM/RAM Used Information					
(2) Area Internal Information					
.....					
(3) General Evaluation Value Information					
.....					

Page Header

Linker name, list name, time and page number are shown in the page header.

(1) ROM/RAM Used Information Display Area

- Lines containing a # character at their head among those output to the ROM/RAM Used Information display area indicate the information specified by the `-ro` or `-ra` options.
- Lines that do not contain a # character at the head of the lines that were output, display the header address and end address of the sections in the valid area and the size of the area that is used including the gap area and the remainder or insufficient values for the sizes of the used areas.
- Areas specified by the `-ro` or `-ra` option, has have the names of their sections that could not be located and the size of the section.
 - S_Addr: Start Address (Hex)
 - E_Addr: End Address (Hex)
 - Size: Area Size (Hex)
 - Remain: Size of the area in the memory (Hex)

The following shows the header symbols.

+: Free Area Size

-: Remainder Area Size

Space: When free/remainder area is 0.

- Name/State: Memory Area Name and Section Name

(2) Area Internal Information Area

The area internal information area displays the free area of the valid area, the used area and the gap area in a map image. The information displayed in this area is information only of the located section with regard to the specified area.

- S_Addr: Area Start Address (Hex)
- E_Addr: Area End Address (Hex)
- Size: Area Size (Hex)
- Name/State: Area Type
 - FREE: Free Area
 - USED: Used Area
 - GAP: Gap Area

(3) General Evaluation Value Information

General Evaluation Value Information shows the following types of information for the overall ROM and RAM areas.

- 1 Total value of the specified area (Total)
- 2 Total value of the used area (Used) (Note: Includes the Gap area.)
- 3 Total value of the free or remainder area (Remainder)

■ Example Display of the Memory Used Information List Field List

The following is an example of the Memory Used Information List Field list display.

S_Addr.	-E_Addr.	Size	Remain	Name/State	C
# 00001000-00001FFF		00001000	-----	RAM1	<-Memory Area Specified in the Option
00001000-00001774		00000775	+0000088B		<-Memory Status of the Section Located
00001000-00001136		00000137	-----	USED	RAM1 Area Information
00001137-00001137		00000001	-----	GAP	
00001138-0000152B		000003F4	-----	USED	
0000152C-0000152F		00000004	-----	GAP	
00001530-00001774		00000245	-----	USED	
00001775-00001FFF		0000088B	-----	FREE	
# 00002000-000023FF		00000400	-----	RAM2	
00002000-00003A1E		00001A1F	-0000161F		<-(*1)
** Not Locate **		00000B28	-----	data01	<-Section Information Not Located (*2)
** Not Locate **		00000EF6	-----	data02	
					RAM2 Area Information
00002000-000023FF		00000400	-----	FREE	
RAM -- Total(00001400) Used(00002194) Remainder(-00000D94) <-All RAM Area Information					
# 000BC000-000BCFFF		00001000	-----	ROM1	
000BBF00-000BDFFF		00002100	-00001100		<-(*3)
					ROM1 Area Information
000BC000-000BCFFF		00001000	-----	USED	
# 000BD000-000BFFFF		00003000	-----	ROM2	
000BD000-		00000000	+00003000		
					ROM2 Area Information
000BD000-000BFFFF		00003000	-----	FREE	
ROM -- Total(00004000) Used(00002100) Remainder(+00001F00) <-All ROM Area Information					

(Note)

- *1. Memory area information that has sections not located that were to be located in the memory area by the automatic locating option indicates the status with added section size. (When the numerical value expression exceeds 0xFFFFFFFF, the lower part of the 32 bit is displayed of that value.)
- *2. When Mode 2 of the automatic location option is specified, this displays the memory area specified last for the section not located (for either the ROM area or the RAM area).
- *3. Sections specified by the user location are included in the memory area which include the section header address.