



1B4 <-> 2B1 = 0° - I
 1B1 <-> 2B4 = 180° + I
 1B3 <-> 2B2 = 90° - Q
 1B2 <-> 2B3 = 270° + Q

MODE	OE	S1	S0	Switches	Phases
TX	0	0	0	1B1/2B1	180/0
TX	0	0	1	2B2/1B2	90/270
TX	0	1	1	1B4/2B4	0/180
TX	0	1	0	2B3/1B3	270/90
RX	1	X	X	All Open	