

INSTRUCTIONS FOR THE 238, 4229, 229, 229A DIAL CORD ROUTING

1. TURN THE INDUCTOR FULLY CW.
2. INSTALL BLACK STRETCH CORD ON RIGHT SIDE OF POINTER.
3. PLACE POINTER ON SUB-PANEL AND TAPE TO PANEL.
4. TIE DACRON CORD TO LEFT END (IN HOLE) OF DIAL POINTER
5. ROUTE DACRON CORD AS BELOW AND TIE SECURELY TO PIN ON INDUCTOR SHAFT.
6. TIE OTHER END OF BLACK STRETCH CORD AROUND POT SHAFT. POINTER SHOULD BE AGAINST RIGHT SIDE PULLEY AND DACRON CORD SHOULD BE TAUT.

