

FR MB2197 TOOL CROSS REFERENCE

DEVICE	MAIN UNIT MB2197-01	POD / EVALUATION BOARD PART NUMBER	STACK / ADAPTER / HEADER /PROBE CABLE PART NUMBER	EVALUATION DEVICE PART NUMBER	SOCKET / CONNECTOR PART NUMBER
MB91101APF	X	NOT REQUIRED	FR-RAM-STACK1-100P-M06	MB91V101ACR	IC149-100-014-B5
MB91101APFV	X	NOT REQUIRED	MB2197-101	MB91V101ACR	IC149-100-025-B5
MB91106PF	X	MB2197-110	MB2197-112 *	MB91V106CR	NQ-PACK100RB
MB91106PFV	X	MB2197-110	MB2197-111 *	MB91V106CR	NQ-PACK100SD
MB91107PFV	X	TBA	TBA	TBA	TBA
MB91F109PF	X	MB2197-110	MB2197-112 *	MB91V106CR	NQ-PACK100RB
MB91F109PFV	X	MB2197-110	MB2197-111 *	MB91V106CR	NQ-PACK100SD
MB91121PFV	X	TBA	TBA	TBA	TBA
MB91110PMT2	X	MB2197-110	MB2197-115 *	MB91V110CR	NQ-PACK144SD
MB91111PMT2	X	MB2197-110	MB2197-115 *	MB91V110CR	NQ-PACK144SD
MB91F361PFV	X	MB2197-120	MB2197-127 *	MB91V360A3-CR	NQ-PACK208SD

OPTIONAL UNIT	PART NO.
MEMORY OVERLAY UNIT	MB2197-90
STARTERKIT	STARTERKITFR
STARTERKIT	STARTERKITMB91360
LID FOR NQ-PACK100RB	HQ-PACK100RB179
LID FOR NQ-PACK100SD	HQ-PACK100SD
LID FOR NQ-PACK144SD	HQ-PACK144SD
LID FOR NQ-PACK208SD	HQ-PACK208SD306

* Includes 1 NQ/HQ-PACK pair