



|    |     |
|----|-----|
| 1  | N/C |
| 2  | O   |
| 3  | N   |
| 4  | L   |
| 5  | N/C |
| 6  | F   |
| 7  | N/C |
| 8  | M   |
| 9  | K   |
| 10 | G   |

**Diagram of Midland 70-1053A Programming Cable -**  
 This connects the 70-195 / 70-295 hand held radios  
 to the XTR / SYN-TECH II programming cable (or to the 70-1080 programmer)

**PIN OUTS ARE LOOKING AT BOTH CABLE CONNECTORS**