
ANT
J501
M-RM
LOCAL
Rx RF
IC901
M37450M4-XXXSP
or
M37450E4-XXXSP
J402 PS10PED4T1BI
GND
NC
NC
CD
SD
RD
CTS
RTS
5V OUT
5V IN
J401 ILS14PS2T2EF
SQ VOL
VOL
GND
NC
MIC GND
CALL LED
DN
UP
PTT IN
MIC IN
S301
S302
S303
S304
J411 ILS15PS2T2EF
TX LED
BUSY LED
LED STB
DSP STB
DSP 3
DSP 2
DSP 1
DSP 0
SP2
5V
SP INT
+B
HANG UP
+B SW OUT
GND
J414 ILG2PS3T2E
SP2
SP1
P416 EMCM0227
AUX1
AUX2
J415 1292R
AUX1
HANG UP GND
HANG UP
SP2
SP INT
SP1
GND
AUX2
13.6V
CA401
J413 P413
EMCS0552M EMCM0522
IC406 TDA7240AV
IC402 HA17805W
IC401 AN6541
IC903 M6M8002L
J409 JM16LS10BAT
Q243 2SC2462LC
ALARM
ALARM/BEEP
POWER CONT
BEEP
F CONT
TEMP
CHECK LED
BACK UP
PTT OUT
MUTE
SIGNAL I/O
CLK
NSQ
DN
UP
5V
9V
+B